

Protocol

1. Download or create structure

1. Folded - AA sequence to AlphaFold server for hairpin structure, randomly choose one of 5 structures
2. Unfolded - Build AA sequence in PyMol, drag to linear form

2. Add Hydrogens

1. Chimera → structure editing → Add H
2. `tleap pdb4amber -i pdbin.pdb -o pdbout.pdb --reduce --dry`

3. tleap system setup

1. Must calculate required ions with <https://www.phys.ksu.edu/personal/schmit/SLTCAP/SLTCAP.html>

```
# Template RNA Hairpin FOLDED PREP
# MUST REMOVE TERMINAL PHOSPHATES
# Run with tleap -s -f leap.in on CL

source leaprc.RNA.OL3
source leaprc.water.tip3p
mol = loadpdb in.pdb
addions mol Na+ 0
**solvateoct mol TIP3PROX 12.0
addionsrand mol Na+ 000 Cl- 000**
savepdb mol out.pdb
saveamberparm mol out.prmtop out.inpcrd
saveamberparm mol out.prmtop out.rst7
check mol
quit
```

4. md 1 Initial minimization: Let solvent relax around restrained solute

1. 1000 steps (500 steepest descents/500 conjugate gradient)
2. 500 kcal/mol-A2 restraints (solute)

5. md2 Second minimization: Let everything relax

1. 2500 steps (1000 steepest descents/1500 conjugate gradient)

6. Defrost (md1): Begin constant volume to warm to proper temperature with restrained solute

1. 100 ps NVT
2. Langevin temperature control 0 -> 300K
3. 25 kcal/mol-A2 restraints (solute)

7. Equilibration (md2): Switch to constant pressure to get proper density while gradually releasing restraints on solute (5-stage release with strong restraints for first 40ps while density is changing most rapidly)

1. 250 ps NPT
2. Langevin temperature control 300K
3. "Weak-coupling" pressure control 1.0bar (~1 atm)
4. 25 -> 5 kcal/mol-A2 restraints(solute)
 1. md2a 25 kcal 50ps
 2. md2b 20 kcal 50ps
 3. md2c 15 kcal 50ps
 4. md2d 10 kcal 50ps
 5. md2e 5 kcal 50ps

8. Equilibration (md3): Release solute restraints and collect data to isotropically scale box size to reflect average volume

1. 200 ps NPT
2. Langevin temperature control 300K
3. "Weak-coupling" pressure control 1.0bar(~1.0atm)

9. Calculate new volume and replace x,y,z in restart file

1. New flag: `ntxo=1`

10. Equilibration (md4): Switch to constant volume and equilibrate with scaled box size

1. 1 ns NVT
2. Remove `ntxo=1` flag

11. Production run: keep the same conditions as the equilibration run

1. 1 microsecond
2. Copy over md4.rst to production folder, rename as md.rst
3. Keep running production for however long is needed for your system until it equilibrates completely.

```
Production run NVT
&ctrl
imin=0,                ## No minimization
irest=1, ntx=5,         ## Restart MD with coordinates
ntbx=1,                ## Periodic boundaries, constant volume
ign=1,                 ## Random seed
cut=10.0,              ## Non-bonded interactions cutoff 10A
ntc=2, ntf=2,          ## ntc=2 Hydrogen bond constraints SHAKE for TIP3P
temp=310.0, temp0=310.0, ## Temp controlled 310K initial, 310k hold
ntt=3, gamma_lmc=0,    ## Langevin thermostat, collision freq. 1.0^-1 ps
ntslim=500000000, dt=0.002, ## ntslim=50,000,000 steps; dt=0.002 ps (2 fs) timestep; total time = 100 ns
ntpr=1000 ntxw=500, ntwr=10000, ## ntpr=Every 1000 steps energy printed to human readable .edout and .edinfo
                                ## ntxw=Every 10000 steps restrt file written ## ntwr=Every 500 steps coordinates written to .mdcrd
/
```

FOR UNFOLDED

1. Production

1. 300 ns
2. Save only last frame
3. Generate average structure, remove all ions and water to send back into min_eq to re-equilibrate system

2. Re-Set up System

1. Add H
2. Add ions, water, set up with tleap

3. Repeat Min_Eq and full production run