## Project Parameters

```
Periodic Boundary Conditions: Truncated octahedral box, min distance 12Å (solvateoct mol TIP3PBOX 12.0)
Force Field: Amber f99 + bsc0 + XOL3 (source leaprc.RNA.OL3)
Water Model: TIP3P (source leaprc.water.tip3p)
Neutralize RNA (addions mol Na+ 0)
Add 1 M NaCl (addionsrand mol Na+ X Cl- X)

Thermostat: Langevin 310K, timestep 2 ps, collison freq 1 ps-1 (temp=310; ntt=3 gamma_ln=1.0)
Barostat: Monte Carlo, 100 step attempt frequency (ntp=1; barostat=2)
Hydrogen Bond Constraints: SHAKE (ntc=2; ntf=2)
Restraints: Keep as standard release through equilibration (restraintmask=':1-12')
Simulation time: Stepwise minimization and equilibration
```

1

#### Download or create structure

- Folded AA sequence to AlphaFold server for hairpin structure, randomly choose
- Unfolded Build AA sequence in PyMol, drag to linear form

### Add Hydrogens

- Chimera → Structure editing → Add H
- tleap pdb4amber -i pdbin.pdb -o pdbout.pdb --reduce -dry

#### tleap system setup

Calculate required ions with <a href="https://www.phys.ksu.edu/personal/schmit/SLTCAP/SLTCAP.html">https://www.phys.ksu.edu/personal/schmit/SLTCAP/SLTCAP.html</a>

```
# Template RNA Hairpin FOLDED PREP
# MUST REMOVE TERMINAL PHOSPHATES
# Run with tleap -s -f leap.in on CL
source leaprc.RNA.OL3
source leaprc.water.tip3p
mol = loadpdb in.pdb
addions mol Na+ 00
**solvateoct mol TIP3PBOX 12.0
addionsrand mol Na+ 000 Cl- 000**
savepdb mol out.pdb
saveamberparm mol out.prmtop out.inpcrd
saveamberparm mol out.prmtop out.rst7
check mol
quit
```

# Initial minimization (min1)

- Let solvent relax around restrained solute
- 1000 steps (500 steepest descent/500 conjugate gradient)
- 500 kcal/mol-Å2 restraints (solute)

Second minimization (min2)

- Let everything relax
- 2500 steps (1000 steepest descents/1500 conjugate gradient)

Defrost (md1)

- Begin constant volume to warm to proper temperature with restrained solute
- 100 ps NVT
- Langevin temperature control 0 →310K
- 25 kcal/mol<sup>-1</sup>-Å<sup>2</sup> restraints (solute)

```
md1 defrost 0 to 310K with restraints on RNA 100ps NVT
&cntrl
imin=0,
irest=0, ntx=1,
ntb=1,
ntr=1, restraint_wt=25.0, restraintmask=':1-12',
cut=10.0,
ntc=2, ntf=2,
ntt=3, gamma_ln=1.0,
tempi=0, temp0=310,
nstlim=50000, dt=0.002,
ntpr=100,
ntw=100,
ntw=100,
ntw=100,
ntw=1000,
//
```

Equilibration (md2)

- Constant pressure to get proper density, gradually reslease restraints on solute.
- 5-stage release with strong restraints for first 50ps while density is most rapidly changing
- 250 ps NPT
- Langevin temperature control 310K
- "Weak-coupling" pressure control 1.0bar (~1 atm)
- 25 -> 5 kcal/mol-Å2 restraints(solute)

```
1. md2a 25 kcal 50ps
2. md2b 20 kcal 50ps
3. md2c 15 kcal 50ps
```

4. md2d 10 kcal 50ps
5. md2e 5 kcal 50ps

md2a-e minimization restraint 25kcal 50ps 310K NPT
&cntrl
imin=0,
irest=1, ntx=5,
ntb=2,
ntp=1, barostat=2,
taup=1.0, pres0=1.0,
ntc=2, ntf=2,
cut=10.0,
ntr=1, restraint\_wt=25.0, restraintmask=':1-12',
ntt=3, gamma\_ln=1.0,
tempi=310.0, tempo=310.0,
nstlim=25000, dt=0.002,
ntpr=100, ntwx=1000, ntwr=1000,

```
! No minimization
! Restart with coord and velocities
! Periodic boundaries constant pressure (NPT)
! Isotropic position scaling, Monte Carlo barostat
! Pressure relaxation time 1.0, reference pressure 1 bar
! ntc=2 Hydrogen bond constraints SHAKE for TIP3P, omitted
! Non-bonded interaction cutoff
! Solute restraints
! Langevin thermostat, collision freq. 1.0-1ps
! Initial temp 310K, reference temp 310K
! Timestep 0.002 ps, 25000 steps (50ps)
! Energy printed/100 steps, coord/100 steps, restart/1000 steps
```

# Equilibration (md3)

• Release solute restraints and isotropically scale box size to reflect average volume

3

- 200 ps NPT
- Langevin temperature control 310K
- "Weak-coupling" pressure control 1.0bar (~1.0atm)

```
md3 equilibration 200ps 310K NPT
&cntrl
imin=0,
irest=1, ntx=5,
ntb=2,
cut=10.0,
nt=2,
ntt=2,
ntt=2,
ntt=3,
gamma_ln=1.0,
tempi=310.0, temp0=310.0,
ntxo-1,
nstlim=100000, dt=0.002,
ntp=100, ntwx=1000,
ntwx=1000,
ntxo-1,
nstlim=100000, dt=0.002,
ntp=100,
ntxo-1,
nstlim=100000, ntwx=1000,
ntyxo-1,
ntxo-1,
nstlim=100000, dt=0.002,
ntyxo-1,
ntxo-1,
nstlim=100000, ntwx=1000,
ntyxo-1,
```

Calculate new volume and replace x,y,z in restart file

• New flag: ntxo=1

```
postmd3_calcboxlength.py
   1.Box length from first three columns of last line in md3.rst
   2.Average volume from md3.mdout
   3.Copy md3.rst to md3_NewVolume.rst, replace first three columns of last line with new box length
```

#### Equilibration (md4)

- Switch to constant volume and equilibrate with scaled box size
- 1 ns NVT
- Remove ntxo=1 flag

```
md4 equilibration 1ns 310K NVT
&cntrl
imin=0, ! No minimization
irest=1, ntx=5, ! Restart with coord and velocities
ntb=1, cut=10.0, ! Periodic boundaries constant volume (NVT)
cut=10.0, ! Non-bonded interaction cutoff
ntc=2, ntf=2, | ntc=2 Hydrogen bond constraints SHAKE for TIP3P, omitted
ntt=3, gamma_ln=1.0, ! Langevin thermostat, collision freq. 1.0-1ps
tempi=310.0, temp0=310.0, ! Initial temp 310K, reference temp 310K
nstlim=500000, dt=0.002, ! Timestep 0.002 ps, 500000 steps (1000ps)
ntpr=500, ntwx=1000, ntwr=100000, ! Energy printed/500 steps, coord/1000 steps, restart/100000 steps
```

Production run: keep the same conditions as the equilibration run

- 1 microsecond
- Copy over md4.rst to production folder, rename as md.rst
- Run production until system fully equilibrates

```
Production run NVT
 &cntrl
  imin=0,
                                               ! \ {\tt No \ minimization}
                                                 Restart MD with coordinates
  irest=1, ntx=5,
                                                  Periodic boundaries, constant volume
  ntb=1,
  ig=-1,
cut=10.0,
                                                 Random seed
                                                 Non-bonded interactions cutoff 10Å
  ntc=2, ntf=2,
                                                  ntc=2 Hydrogen bond constraints SHAKE for TIP3P
  ntt=3, gamma_ln=1.0,
tempi=310.0, temp0=310.0,
nstlim=50000000, dt=0.002,
                                                 Langevin thermostat, collision freq. 1.0<sup>-1</sup>ps
Initial temp 310K, reference temp 310K
50,000,000 steps, 0.002 ps (2 fs) timestep, total time = 100 ns
  ntpr=1000 ntwx=500, ntwr=10000, ! Energy printed to mdinfo mdout/1000 steps, coord written/500 steps, rst written/10000 steps
```